


W-937-40 Wheel Balancer Parts Manual




WEAVER
E Q U I P M E N T


Please read this manual before operation




ITEM	PART.No	DESCRIPTION.	QT.Y
1	B-12-1300000	BOX WELDING	1
2	TB-P-0600000L	BALANCER SPINDLE	1
3	TB-P-0110000	PRESS SENSOR ASSEMBLY	1
4	B-01-1000100	MOTOR HOLDER	1
5	GB5783-M8×20	HEXANGULAR BOLT	4
6	GB93-8	STANDARD SPRING WASHER	4
7	GB95-8	FLAT WASHER	4
8	TB-E-1500200	POWER CABLE ASSEMBLY	1
9	GB973-M5×8-H	CROSS PANHEAD SCREW	2
10	TB-S-0100009	CONE HANG HANDLE	2
11	GB5783-M10×25	HEXANGULAR BOLT	4
12	GB93-10	STANDARD SPRING WASHER	4
13	GB95-10	FLAT WASHER	4
14	B-01-1008001	SWITCH CONNECTION LINE	1
15	B-01-1008002	POWER BOARD CONNECTIONS	1
16	B-01-1008003	DISPLAY PANEL CABLE	1
17	B-01-1008004	DISPLAY PANEL CABLE	1
18	B-01-1008005	EARTH WIRE	1
19	B-01-1000006	WEDGE BELT(940mm)	1
20	GB70.1-M6×16	INNER HEXA CYLINDRICAL SCREW	4
21	GB93-6	STANDARD SPRING WASHER	5
22	GB95-6	FLAT WASHER	5
23	B-53-1000007	NUT M4	4
24	GB818-M6×12-H	CROSS PANHEAD SCREW	1
25	B-53-1000006	SCREW M4	4
26	C-71-1000019	RUBBER GROMMET	1
27	C-54-1000015	STOP-UP	1
28	B-53-1000008	FIX PLATE	4
29	B-53-1000009	NYLON BELT	5
30	B-01-1000010	COMPUTER BOARD	1
31	TB-E-1220000	POWER SUPPLY ASSEM	1
32	TB-E-9001110	MOTOR ASSEMBLY PART	1
33	B-12-1200000	LEAD WEIGHTS COVER ASSEMBLY	1
34	TB-E-1001101	POWER SWITCH	1
35	B-01-1008006	OPTICBACKPANEL CABLE	1
36	TB-E-1006005	JUMPER No4	1
37	B-01-1000008	ASSESS HOLES COVER	1
38	B-73-1000019	E-RINGS	1




ITEM	PART.No	DESCRIPTION.	QT.Y
1	TB-P-0101000	FIXING SHAFT WELDING	1
2	TB-P-0602000L	MAIN SHAFT WELDING	1
3	TB-P-0100001	BEARING PRESS HOUSING	1
4	TB-P-0100002	PHOTOELECTRIC SET	1
5	TB-P-0100003	PHOTOELECTRIC TOOTH	1
6	TB-P-0100004	ENCODER CELL PLATE	1
7	B-73-1215000	BALANCER SPINDLE	1
8	TB-P-0100009	SPRING	1
9	TB-P-0300008	SPRING PRESS COVER	1
10	TB-P-0100011	ANGLE SENSOR	1
11	TB-P-0300032	40CONE 54-78	1
12	TB-P-0300033	CONE 74-108	1
13	TB-P-0300034	CONE 90-158	1
14	GB276-6005	DEEP GROOVE BALL BEARINGS	1
15	GB276-6006	DEEP GROOVE BALL BEARINGS	1
16	GB894.2-25	SHAFT ELATIC RETAINING RING B-TYPE	1
17	GB894.2-30	SHAFT ELATIC RETAINING RING B-TYPE	1
18	GB95-3	FLAT WASHER	2
19	GB93-3	STANDARD SPRING WASHER	2
20	GB818-M3×8-H	CROSS PANHEAD SCREW	2
21	GB70.1-M5×16	INNER HEXA CYLINDRICAL SCREW	4
22	GB6170-M3	HEXANGULAR NUT 1-TYPE	2
23	TB-P-0300031	40CONE 42-65	1
24	TB-P-0300009A	CLAMP RING	1
25	GB9074.4-M4×8	SCREW	6




ITEM	PART.No	DESCRIPTION.	QT
1	TB-P-0103000	SCREW WITH HANGING RING	1
2	TB-P-0100006	FULL BOTTON SCREW	1
3	TB-P-0100100	PIEZO ASSEMBLY	1
4	TB-P-0100005	PRESSING WASHER	2
5	DIN 6796 - 10	SPRING PIEZO WAHSER	4
6	GB95-10	FLAT WASHER	5
7	GB93-10	STANDARD SPRING WASHER	1
8	GB6170-M10	HEXANGULAR NUT 1-TYPE	5




ITEM	PART. No	DESCRIPTION.	QT. Y
1	B-12-1000001	CPU-900	1
2	B-56-1500105	CPU GROUND WIRE	1
3	TB-E-1211002	PLASTIC CLIPPER	4
4	GB845-ST3.5×13 H C	CROSS PANHEAD TAPPING SCREW	1




ITEM	PART. No	DESCRIPTION.	QT
1	TB-E-1211100	POWER BOARD	1
2	TB-E-1211001	SUPPORT PLATE	1
3	TB-E-1211002	PLASTIC CLIPPER	2
4	GB818-M3×8-H	CROSS PANHEAD SCREW	2
5	GB95-3	FLAT WASHER	2
6	GB93-3	STANDARD SPRING WASHER	2
7	GB6170-M3	HEXANGULAR NUT 1-TYPE	2
8	TB-E-1006004	JUMPER N04	1
9	TB-E-1211268	ANABIOSIS RESISTANCE	1
10	GB818-M4×10-H	CROSS PANHEAD SCREW	2
11	TB-E-1258110	TRANSFORMATOR 110V	1
12	GB845-ST4.2×13 H C	CROSS PANHEAD TAPPING SCREW	4
13	TB-E-1210100	EARTH WIRE	1




ITEM	PART. No	DESCRIPTION.	QT. Y
1	TB-E-9000110	MOTOR 250W110V	1
2	B-53-1000003	MOTOR BELT PULLEY	1
3	GB1096-5×5×20	COMMON FLAT KEY	1




ITEM	PART. No	DESCRIPTION.	QT. Y
1	B-12-1210000	LEAD WEIGHTS COVER THE MINISTRY OF INSTALLATION	1
2	TB-L-0101000	SCALE ASSEMBLY	1
3	GB973-M5×12-H	CROSS PANHEAD SCREW	2



ITEM	PART. No	DESCRIPTION.	QT. Y
1	B-12-1210003	IMD PANEL	1
2	B-12-1210004	WASHER	1
3	B-56-1210008	SREEN DAMP COVER	8
4	B-12-1210002	DISPLAY PANEL	1
5	B-12-1210006	BUTTEN	1
6	GB96. 1-3	LARGE WASHER A GRADE	8
7	GB889. 1-M3	1-TYPE PREVAILING TORQUE TYPE HEXAGON LOCK NUT	8
8	B-12-1210001	WEIGHT TRAY	1
9	GB845-ST2. 9×9. 5 H C	CROSS PANHEAD TAPPING SCREW	4



ITEM	PART. No	DESCRIPTION.	QT. Y
1	TB-L-0101001	SCALE ROD	1
2	TB-L-0101002	HARNESS	1
3	TB-L-0101003	SCALE HOLDER	1
4	TB-L-0101004	SCALE	1
5	TB-L-0101005	HARNESS	1
6	TB-L-0101006	SCALE HANDLE	1
7	TB-L-0101007	SPRING	1
8	GB70. 1-M6×16	INNER HEXA CYLINDRICAL SCREW	2
9	GB95-6	FLAT WASHER	1
10	GB894. 1-25	SHAFT ELATIC BIG RETAINING RING A-TYPE	2
11	TB-L-0100200	SCALE HANDLE	1



ITEM	PART.No	DESCRIPTION.	QT.Y
1	TB-S-0100006	ACCESSORY BOX	1
2	TB-S-0100007	TRAY	1
3	TB-S-0100001	BOWL	1
4	TB-S-0100002	BOWL EDGE	1
5	TB-S-0100100	CALIPER ASSEMBLY	1
6	TB-S-0100003	WEIGHT(100g)	1
7	TB-K-0200000	QUICK NUT	1
8	TB-S-0100005	BALANCE HAMMAR	1
9	TB-P-0200010	FLANGE	1