

## **Multi-Point Lift Inspection**

Location Name												Date	·					
Address												none	#			_		
Lift Seria	al #	Model #											Bay #					
	Surface	2 Post	2 Post 4 Post Scissor Low/Mid Rise Hinge											ŀ	Hydraulic Portable			
Lift Type	Inground	Single Post	T	Twi	in Post	П	High	Pressure						For	e & Af	ft		
Capacity Capacity Decal Located On Lift Accessibility of owners instructions & lifting po																Pass	Ne	eded
			Con	mon Ins	pectio	n Points	s All I	Lifts					Dana		Attn	F-ii		N/A
Access	ibility and re	eadability of sa											Pass	N	eded	Fail		N/A
Confirm	n adequacy	of clearances	arour	nd lift														一
Examir	e structural	components in	nclud	ing welds	for sign	s of fatigu	e, ove	rloading	, misuse	;								
		for proper ope			_	-												一
Check	fluid levels a	and contamina	tion															
Examir	e electrical	components &	wirir	ıg														而
Check	all points re	quiring lubricat	ion															一
Check	for proper ir	nstallation and	condi	tion of spo	otting di	sh												
On lifts	employing	adapters, chec	k cor	dition and	d proper	operation	1											
Are Ext	ended Heig	ht adapters av	ailab	е														
Check	all accessor	ries for constru	ction	and labeli	ing													
Check	all fastening	devices for tig	htne	ss includir	ng floor	anchor bo	lts											
On lifts	incorporati	ng overhead st	ructu	res, verify	the safe	ety shutofl	opera	ates prop	erly									
Operate the lift and check the operation of the lift locks, including latch cables																		
On lifts incorporating secondary latch devices, check operation and condition																		
		Hose	es, P	iping, Tı	ubing 8	& Hydraı	ulic C	ylinder	'S									
Check	all accessib	le piping, tubin	g, ho	se, valves	, fittings	for visible	e leak	s & prope	er routing	3								$\underline{\sqcup}$
Check	hydraulic cy	linders for smo		•														
la sa sa sa						s & Shea		d= === !=									_	$\overline{}$
Inspect sheaves for proper alignment and cracks. Ensure sheave shields are in place																$\blacksquare$		
Inspect all cables and/or chains for frays, stretching, corrosion, cracking and proper adjustment															<del></del>	믬		
Check the tracking and routing of cables and chains  Lifts using swing arms, runways or platforms																		
On lifts using swing arms, runways or platforms  On lifts using swing arms, check telescoping stops															$\overline{\Box}$			
On lifts requiring swing arm restraints, check for proper function and abnormal wear																_	Ħ	
On lifts using runways, check to ensure proper operation of all features																		Ħ
On lifts equipped with platforms, railings or stairways, check to ensure proper operation of all features																	_	Ħ
						d Lifts		•										
Report	water in sul	b-floor pits or e	nclos	ures														
On air-	oil lifts chec	k for low oil co	ntrol															
Confirm	n rotation pr	evention devic	e on	single pos	t lifts													
On lifts which incorporate trench covers, verify proper operation and abnormal deformation																		
Check integrity of tamper resistant seals on relief valves																		
Inspect plungers for signs of rust, corrosion or damage																		
Confirm single point operation of multiple powered posts																		
Hydraulic Portable Lifts																		
		systems for pr	oper	operation	and lub	rication											<u></u>	ᆜ
	-	ndividual units															<u></u>	ᆜ
Run lift	through full	cycle and veri	fy pro	per shut	off at top	and bott	om of	travel										

Lift Inspector Signature\_\_\_\_\_