W-987 QUICK START GUIDE

(BEGIN HERE)



QUICK START GUIDE



Step 1: Visit www.derekweaver.com/ (visible on smartphones and tablets)

Step 2: Select "Videos"



Step 3: Choose "Wheel Balancer Videos"

		SHOP EQU	UPPT CO. JIPMENT SINCE Car Rotisserie	E 1984	uipment	Veaver Wear	81	sign out 7-560	` ⊭ cart -9510
About Testimonials	Support	FAQ	Contact	Press Le	earn V	ideos	S	earch the stor	e Q
BIKER'S GARAGE Motorcycle Lifts Motorcycle Jacks Motorcycle Lift Parts & Accessories		East Coa Warehouse		e Open		Car Lift Videos Car Rotisserie Videos Tire Changer Videos Wheel Balancer		RODDER'S GARAGE 2 Post Lifts 4 Post Lifts 2 Post Lift Parts & Accessories 4 Post Lift Parts &	
K & L Supply Parts & Accessories Motorcycle Tire Changers Motorcycle Wheel Balancers Motorcycle Tire Changer / Wheel			2 day shipping (lift models Learn more	on most s	*	Videos		Accessories	

Step 4: Select the model number of your machine (found on the back of machine)

All videos are for demonostration purposes. You must wear manufacturer recommended protective gear when using equipment and follow all safety precautions in the manufacturer's operation manual.

W-937 Wheel Balancer Videos W-957 Wheel Balancer Videos W-977 Wheel Balancer Videos W-987 Wheel Balancer Videos Select the model number of your machine

Complete these steps in order:

Step 5: Watch and Perform Video titled "W-987 User Settings"

• This will help ensure all of the settings on your machine are correct.

Step 6: Watch and Perform Video titled "Mounting Instructions"

- This will help ensure that you are mounting wheels correctly.
- If the mounting is not correct, it WILL lead to inaccurate balancing.

Step 7: Watch and Perform Video titled "W-987 Calibration"

- This video will help you perform the Calibration Procedure correctly.
- If the calibration procedure is performed incorrectly it WILL lead to inaccurate balancing; make sure you follow these instructions before beginning:
 - ONLY use a 15" or 16" Steel Automotive Wheel in GREAT CONDITION.
 - DO NOT USE a Trailer Wheel or Spare.
 - DO NOT USE the spacer ring during calibration.
 - Refer to "Mounting Instructions" video when mounting your wheel.
 - ONLY USE the Calibration Weight that was provided with your balancer, using third party weights WILL cause inaccurate balancing.

-----If you intend to use Tape-on weights, continue to Step 8------

Step 8: Watch and Perform Video titled "W-987 ALU Smart Modes"

- This video will help you balance aluminum or alloy wheels with tape-on weights.
- If the ALU Smart Modes are performed incorrectly it WILL lead to inaccurate balancing.

When you have completed these steps, You are Ready to Enjoy Accurate Wheel Balancing!

Thank you for choosing Weaver Equipment. We appreciate your business and look forward to helping your continued success!